

# HYSOLV FOOTCHECK THE PROFESSIONALS CHOICE

Footcheck is a pre-calibrated footbath providing a rapid, simple and convenient way to accurately and consistently achieve the correct concentration for disinfectants used as a part of a biosecurity programme.

- **REMEMBER:** Fill in your audit sticker and/or record sheet.

## HOW TO USE FOOTCHECK



**Omnicide**  
For Complete Bio-Security



- 1 Position footbath on a level floor near a suitable wall. 2 On level ground, prop the bath against a wall to achieve an angle of 45 degrees (as illustrated) and lift the lid. 3 Carefully pour concentrated Omnicide disinfectant into the appropriate internal measuring chamber, or chambers. Fill the 1% chamber for 1% concentration (half fill for 0.5% concentration). Fill the 2% chamber for 2% concentration or fill both 1% and 2% chambers for 3% concentration. For 4% concentration fill both 1% and 2% chambers (as 3% concentration) - see point 5 for water level instructions. 4 Lower footbath so that the base is flat on the floor.



- 5 Fill footbath with clean water to final fill line (15 litres) or to level B fill for 4% concentration (11.25 litres). Swirl bath contents to mix disinfectant. 6 Complete an audit sticker and apply to front of footbath in the space provided. 7 Keep lid closed when not in use to maintain efficacy by keeping contents clean, reducing evaporation or dilution. 8 Dispose of used contents responsibly and in accordance with the disinfectant instructions.

## FOOTWEAR DISINFECTION



- Disinfection is only effective after thorough cleaning – remove excess soil and organic matter before dipping footwear.
- Replace contents of the Footcheck bath at least once a week; more frequently if the disinfectant becomes heavily soiled or inactivated.



Tel +44 (0)2476 639739  
Fax +44 (0)2476 639719  
Website [www.mirus.com](http://www.mirus.com)  
E-mail [healthcare@mirus.com](mailto:healthcare@mirus.com)